Setting up your Mizar and Samsung display

Your Mizar turns the Samsung display into a Nimbus art frame.

Before you start

- **Two deliveries:** the Samsung display and its wall mount ship separately from our supplier. Your Mizar and its cables come from us in a separate box.
- **In our box:** your Mizar, its power supply, a short HDMI cable, a Samsung control cable (USB on one end, a small round plug on the other), and this sheet.
- **Your home Wi-Fi name and password.** If your router has both 2.4 GHz and 5 GHz networks, choose the 2.4 GHz one.
- **Your phone has Bluetooth turned on.** On Android, also allow the Nimbus app to use your location when it asks.
- **Your Nimbus sign-in:** the email and password you used when you ordered.

Set it up

1. **Hang the Samsung display** near an outlet, using the wall mount and its instructions.
2. **Connect the HDMI cable.** The small end goes into the Mizar's HDMI port **right next to the power port**. The large end goes into the Samsung display's **HDMI 1** port.
   The Mizar has two small HDMI ports. Use the one next to the power port, or the picture may not appear.
3. **Connect the Samsung control cable.** The USB end goes into any USB port on the Mizar. The small round plug goes into the Samsung display's **RS232C IN** jack: the one right **next to the headphone jack**. The jacks are marked with small pictures, not words. IN shows an arrow pointing **into** a box.
   It lets Nimbus turn the screen off at night and set its brightness.
4. **Plug in the Mizar's power supply, then the Samsung display's power cord.**
5. **Finish Samsung's first-start setup** with the Samsung remote:
   Language: your choice · Set Up Network: **Skip**, then Skip again (no network needed) · Installation Type: **Manual Setup** · Display Orientation: **Landscape**, even if your display hangs tall · Player Selection: leave **MagicINFO S Player** and press Next · MagicINFO Server: **Skip** · Current Time: Next · PIN: choose any 6 digits (for example 111111), enter it twice, and **write it down** (the display asks for it before its security settings).
   On a display hung tall, Samsung's menus turn sideways after the Landscape step. That's expected; the Mizar turns your art the right way itself.
6. **Turn on Input Signal Plus** for the Mizar's picture. With the Nimbus screen showing (if it isn't, press **Source** and pick **HDMI 1**), press **Menu** on the remote and go to **Picture > Advanced Settings > Input Signal Plus**, and set it to **On**.
   This lets the Mizar show your art at full quality. The menus may still appear sideways.
7. **Get the Nimbus app** for iPhone or Android, open it and sign in. On the Frames screen, tap **+**, then **Set Up New Frame**, and follow the steps with your phone near the Mizar. The app connects it to your Wi-Fi and adds it to your account.
   "Loading your playlist" shows for a moment, then your art appears.

Scan to get the Nimbus app

Good to know

- **Dark screen at night?** That's normal. The Mizar turns the screen off at night on a schedule you can change in the app.
- **Nimbus screen not showing** after Samsung's setup, or "No signal"? Press **Source** on the remote and pick **HDMI 1** (or whichever HDMI port the Mizar is in). Still nothing? Check the cable is in the Mizar port next to the power port, then unplug and replug the Mizar's power.

Stuck? Give it a few minutes, then email or call us. We're real people and glad to help.
support@nimbusdigitalart.com · **800-640-6171** · nimbusdigitalart.com