Setting up your Mizar

Your Mizar turns your TV or display into a Nimbus art frame.

Before you start

- **In the box:** your Mizar, its power supply, and this sheet. The TV kit adds a 6-foot HDMI cable. **No TV kit?** You'll need a **micro-HDMI to HDMI cable** (sold online and at electronics stores) to reach a TV or display with an HDMI input. A 4K screen shows your art best.
- **Your home Wi-Fi name and password.** If your router has both 2.4 GHz and 5 GHz networks, choose the 2.4 GHz one.
- **Your phone has Bluetooth turned on.** On Android, also allow the Nimbus app to use your location when it asks.
- **Your Nimbus sign-in:** the email and password for your Nimbus account.

Set it up

1. **On a TV, set two things** using its remote and settings menu (on a computer display, skip to step 2):
   Turn on HDMI-CEC. Each brand names it differently: Samsung **Anynet+**, LG **SimpLink**, Sony **Bravia Sync**, Philips **EasyLink**, Vizio **CEC**. This lets the Mizar turn the TV off at night and back on in the morning.
   Turn off any auto power-off or eco sleep timer, if your TV has one. Many TVs switch themselves off after a few hours without a remote press, which would turn your art off in the middle of the day.
2. **Connect the HDMI cable.** The small end goes into the Mizar's HDMI port **right next to the power port**. The large end goes into any HDMI port on your screen.
   The Mizar has two small HDMI ports. Use the one next to the power port, or the picture may not appear.
3. **Plug in the Mizar's power supply.** On a TV with HDMI-CEC, the Mizar turns the TV on and switches it to the right input by itself; on a display, turn it on and choose that HDMI input. Within a minute or two the Nimbus setup screen appears.
   On the first start with a 4K screen, the Mizar restarts once by itself after a couple of minutes. That's normal.
4. **Get the Nimbus app** for iPhone or Android, open it and sign in. On the Frames screen, tap **+**, then **Set Up New Frame**, and follow the steps with your phone near the Mizar. The app connects it to your Wi-Fi and adds it to your account.
   "Loading your playlist" shows for a moment, then your art appears.

Scan to get the Nimbus app

Good to know

- **Screen off at night?** That's normal. The Mizar puts the screen to sleep at night and wakes it in the morning, on a schedule you can change in the app.
- **TV didn't turn on in the morning?** Your TV may not support HDMI-CEC, or it's turned off. Check the setting in step 1. Without it, the Mizar can't switch the TV on, so turn it on with the remote and the art comes right back.
- **Using a computer display?** At night the Mizar turns its picture off, and most displays go to sleep on their own. They wake when the picture comes back in the morning. If yours stays asleep or shows "No signal", press its power button, or turn off its auto power-off timer.
- **Edges of the picture cut off?** In your TV's picture settings, set the picture size to **Screen Fit**, **Just Scan** or **Full Pixel** (the name depends on the brand).
- **"No signal" on the screen** (even after a brief startup screen)? The cable is probably in the wrong Mizar port. Unplug the Mizar's power, move the HDMI cable to the port right next to the power port, then plug power back in. Also check that the screen is on the input the Mizar is plugged into.
- **Something stuck?** Give it a few minutes. If it's still stuck, email or call us and we'll help.

Questions? We're real people and glad to help.
support@nimbusdigitalart.com · **800-640-6171** · nimbusdigitalart.com